Grip Tech

16 Strand Aramid Rope Grip

APPLICATIONS

- Cable installation
- Cable maintenance
- Cable towing
- Strain relief
- Applicable to any cylindrical surface including wire and fibre rope

  Caution: Test Grip Tech on desired surface before use

RANGE/TECHNICAL

Single eye connection with multiple grippy Technora®/Polyester mottled hollow braid legs to allow safe, flexible, easy handling and installation for the hauling application

FEATURES

- Quick, easy, secure cable eye attachment
- Strong and light weight
- Texturised for extra grip
- Low stretch
- Flexible, compact and easy to handle
- High abrasion resistance
- Max. operating temperature of 500°C
- Certified tonnage rating
- Colour coding
- Traceable ID tags

Product Code	Colour	Breakload (t)	SWL (t)	Cable Size Range (mm)	Leg Length (m)	Dia. of Eye (mm)
BRS005GT	Pink	5	1	5 - 20	1.5	14
BRS015GT	Orange	15	3	10 - 30	2.5	22
BRS020GT	Yellow	20	4	15 - 35	3.0	24
BRS030GT	Green	30	6	20 - 40	5.0	30
BRS080GT	Blue	80	16	30 - 90	8.5	42
BRS125GT	Purple	125	25	50 - 100	10	48
BRS200GT	Grey	200	40	90 - 150	15	64

How to install Grip Tech Rope Grip

Note: These instructions are a general guideline and do not need to be followed exactly.

WHAT YOU NEED: Tape measure and electrical tape

INSTRUCTIONS

1. Secure the GripTec eye with electrical tape.

2. Mark off 12 crossover points with electrical tape, starting at 12 x cable diameter and decreasing by 1 until you reach 1 x cable diameter (12 x ∅, 11 x ∅ ,10 x ∅… 1 x ∅).


3. Take 2 legs and cross them over **behind the cable**, halfway between the eye and the first mark, then around to the **front of the cable** and cross over the first mark.

4. Repeat step 3 until you reach the last mark.

5. Secure each end with one of the following:
1. Clove hitch
2. Rolling hitch
3. Electrical tape
(for tight spaces)

6. With the last two legs, repeat steps 2 – 5, this time making each crossover on the **opposite side** of the crossover point of the first 2 legs.